



# **CX-93M-12LS Electromagnetic Shear Lock**

Installation Instructions

#### **This Package Includes:**

#8 x 8" Self Tapping Screws M5 x 8 Flatwashers

#### **Specifications**

Shear Holding Force	Up to 1200lbs. (545kg)	
Voltage Input	12VDC / 24VDC	
<b>Current Draw</b>	310mA / 180mA	
Lock and Armature Gap	5/64" (2mm)	
Operating Temperature	-4°F to 122°F (-20°C to +50°C)	
Door Monitor Contact Rating	0.5A @ 28V DC	
Lock Dimensions	7 1/4" L x 1 3/16" W x 1" D (181mm x 30mm x 25mm)	
Armature Dimensions	7 1/4" L x 1 3/16" W x 3/4" D (181mm x 30mm x 20mm)	


#### **Important Notice:**

- 1. Open pocket hole for armature plate in the door frame using the sticker template provided.
- 2. Attach the armature plate to the door with the hardware provided to right.
- 3. With the door closed, mark the door frame at the edge of the armature in order to properly align the electromagnet to the armature.
- 4. Mortise a hole in the door frame for the lock  $(7 \ 1/4^{\circ}L \ x \ 1 \ 3/8^{\circ}W \ x \ 1^{\circ}D)$




## **Basic Installation Concept & Accessories**

### **Electromagnetic Shear Lock Diagram**




### **Assembled Armature Plate Horizontal Diagram**




### **General Installation Steps and Maintainance:**


- Mark a center line on the door header frame, where the assembled armature is to be installed.
- 2. Cut and drill according to the size of the mounting bracket.
- Connect wiring according to wiring instruction shown below; then mount the shear lock and assembled armature onto the door frame and door.
- 4. For a wider gap between the door & door frame, use steel flat washers to adjust the gap between lock and armature.
- 5. Connect the power wires according to the instructions and test the system.
- 6. It is recommended to apply a light coat of silicon lubricant to the mating surfaces on a monthly basis to prevent rust.



NOTE: Flat washers are only used to adjust armature magnet when the door frame has more than a 5/64" (2mm) gap.



Time	SW1	SW2
3	ON	ON
6	ON	OFF
9	OFF	ON
12	OFF	OFF



Set the jumper position according to the power input before turning ON the power.







Relays & Timers



CAMDEN DOOR CONTROLS

5502 Timberlea Blvd., Mississauga, ON Canada L4W 2T7 www.camdencontrols.com Toll Free: 1.877.226.3369



File: CX-93M-12LS ManualR1.indd Revised: 06/02/2018 Part No.: 40-82B214